

**GPQM96**

**Power Quality Meter**

**User Manual**

---

## TABLE OF CONTENTS

1. SAFETY PRECAUTIONS.....	1
2. PRODUCT DESCRIPTION .....	1
2.1 OVERVIEW .....	1
2.2 EXTEND MODULES.....	1
2.3 MEASUREMENT .....	2
2.4 REAL-TIME MEASUREMENT.....	3
2.5 ENERGY METERING AND TARIFF METER READING .....	4
2.6 ENERGY QUALITY .....	6
2.7 DEMAND RECORD.....	10
2.8 EVENT RECORD .....	10
2.9 HELP INFORMATION .....	11
2.10 EXTEND MODULE.....	11
3 INSTALLATION AND WIRING.....	15
3.1 OUTLINE DIMENSION .....	15
3.2 INSTALLATION METHOD.....	15
3.3 WIRING .....	16
3.4 SIGNAL WIRING DIAGRAM .....	17
4. OPERATION .....	18
4.1 PANEL DESCRIPTION .....	18
5 SETTING .....	19
5.1 SIGNS FOR KEYS AND CORRESPONDING FUNCTIONS.....	19
5.2 PROGRAMMING AND SETTING MENU .....	20
5.3 EXAMPLE FOR PROGRAMMING OPERATION .....	29
6. COMMUNICATION .....	30
7. TECHNICAL SPECIFICATIONS .....	31

---

## 1. Safety Precautions

The manufacturer shall not be held responsible for failure to comply with the instructions in this manual.

The equipment must be installed and serviced only by qualified personnel.

Never work alone.

Prior to any work on or in the equipment, isolate the voltage inputs and auxiliary power supplies, short the secondary of all CT, but never short the secondary of PT.

Always use a properly rated voltage sensing device to conform that all power is off.

### **Risk of damaging device**

- ◆ The voltage of the auxiliary power supply is beyond the rated range.
- ◆ The frequency of the power distribution system is beyond the rated range.
- ◆ The input polarity of the voltage or the current is wired improperly.

## 2. Product description

### 2.1 Overview

GPQM96 is equipped with electrical variable measurement, energy metering and power quality analysis functions. GPQM96 also can be extended with I/O modules for monitoring and controlling equipment at field, realizing system integration with different smart electricity distribution system and energy management system, and sharing monitoring data and energy data.

### 2.2 Extend modules

GPQM96 has two extension interfaces for connecting modules and expand functions. Please take attention to the following points when connecting modules to GPQM96.

- a) Two modules for one interface at most, and four modules for GPQM96 at most;

Module type	Description
1	4 digital inputs
2	2 relay outputs
3	2 analog inputs: mA
4	2 analog outputs: mA
5	Com module - RJ45, Modbus/TCP
6	Com module - DB9, Profibus-DP
7	Com module - additional RS485, Modbus-RTU
8	Com module - BACnet/MSTP communication
9	Com module - BACnet/IP communication
Remarks	Max 4 extended module Only 1 additional Com module can be add-on


### 2.3 Measurement

The following list shows variables which can be measured by GPQM96 including relative variables calculated from basic electrical parameters.

Measurement variable	Instant	Max	Min	Demand	Sum	Unit
V1/V2/V3	●	●	●	—	—	[V,kV]
V12/V23/V31	●	●	●	—	—	[V,kV]
I1/I2/I3	●	●	●	●	—	[A,kA]
F	●	●	●	—	—	[Hz]
P1/P2/P3	●	—	—	—	—	[kW,MW,GW]
P	●	●	●	●	—	[kW,MW,GW]
Q1/Q2/Q3	●	—	—	—	—	[kvar,Mvar,Gvar]
Q	●	●	●	●	—	[kvar,Mvar,Gvar]
S1/S2/S3	●	—	—	—	—	[kVA,MVA,GVA]
S	●	●	●	●	—	[kVA,MVA,GVA]
PF1/PF2/PF3	●	—	—	—	—	—
PF	●	●	●	—	—	—

EP+/EP-	—	—	—	—	●	[kWh,MWh,GWh]
EQ1/EQ2/EQ3/EQ4	—	—	—	—	●	[kvarh,Mvarh,Gvarh]
THDV1/THDV2/THDV3	●	—	—	—	—	[%]
THDI1/THDI2/THDI3	●	—	—	—	—	[%]
Harmonic RMS-U (1~63th)	●	—	—	—	—	[%]
Harmonic RMS-I (1~63th)	●	—	—	—	—	[%]
Unbalance-U	●	—	—	—	—	[%]
Unbalance-I	●	—	—	—	—	[%]

## 2.4 Real-time measurement

 <p>       ◀ L-N Voltage ▶ 1.1        V1 220.1 v min 000.0 v max 230.1 v        V2 220.2 v min 000.0 v max 230.2 v        V3 220.3 v min 000.0 v max 230.3 v        Vavg 220.2 v        ◀ ▶ ⏪ ⏩     </p>	<p>Left picture shows three phase instantaneous voltage, average voltage, max. voltage and min. voltage. Click ◀ or ▶ to check other pages, press ⏪ to return to main interface.</p>
---	--

## 2.5 Energy metering and tariff meter reading

This meter has excellent energy metering functions as follows:

- Total bi-direction active and reactive energy metering
- Phase separated bi-direction active and reactive energy metering
- Fundamental energy metering;
- Four-quadrant reactive energy metering;
- Apparent energy metering;
- Tariff energy metering

The meter shows primary value. Primary value is equal to the secondary value multiplied by voltage or current transformer ratio. Secondary value is the reference to all of the energy. The smallest resolution ratio of secondary value is 1Wh or 1varh. The smallest resolution ratio of energy shown on meter is 0.01kWh or 0.01kvarh.

The storage range of energy is secondary energy 4294967295 Wh, and the display range of energy is primary energy 9999999999 kWh (99.9 billion). The data will not exceed the range if the meter is in its mean time between failures. User can clear the energy data after entering correct password.

Tariff energy: the meter has two sets of tariffs with four kinds of rates in twelve time zones. It starts energy metering in one time zone according to digital input status.

### 2.5.1 Tariff energy

#### ① Rate number

Rate number is used to indicate the present tariff of working meter. T 1 indicates Tip rate; T2 indicates Peak rate; T3 indicates Flat rate; T4 means valley rate.

#### ② Time period

One day can be divided into 12 time periods at most in the meter. The time period must be continuous, which means end time of the first time period is start time of the second time period.

#### ③ Rate schedule

Different rate schedules can be preset in the meter. They can perform different tariff in the specified time period. Up to 4 rates can be preset. During programming, rate schedule number is used to indicate what tariff that the meter performs. 1 indicates the first rate schedule.

#### ④ Holiday

Holiday includes regular holidays(22 days) and irregular holidays(60 days), a total of 82 days.

Regular holidays means the same annual holiday that nation has stipulated, such as January 1<sup>st</sup>, May 1<sup>st</sup>, etc. It can be set according to the requirement. Irregular holiday means annual holidays stipulated by different nations, such as Spring Festive (February, 9<sup>th</sup>, 2005). It can be set according to the requirement. The tariff for holiday can be any one in the four tariffs.

⑤ Weekly tariff



Each of the four rates is available for seven days in a week.




⑥ Monthly tariff

Each of the four rates is available for each month.

⑦ Priority order of tariff

There are two modes to perform tariffs: holiday tariff and monthly tariff. In holiday tariff mode, the holiday tariff will be performed if the day is holiday, otherwise the weekly tariff will be performed. In monthly tariff mode, it will be performed according to the rate schedule that is set monthly.

 <p>Imp/Exp Energy 2.1</p> <p>+ 00000025452.000 kWh</p> <p>- 00000005262.000 kWh</p> <p>+ 00000000302.000 kvarh</p> <p>- 00000000162.000 kvarh</p>	<p>Left picture shows bi-direction active/reactive energy.</p> <p>EP+= 25452kWh,</p> <p>EP- = 5262kWh,</p> <p>EQ+ = 302kvarh,</p> <p>EQ- = 162kvarh.</p>
 <p>L1 Energy 2.2</p> <p>+ 00000015452.000 kWh</p> <p>- 00000002262.000 kWh</p> <p>+ 00000000202.000 kvarh</p> <p>- 00000000062.000 kvarh</p>	<p>Left picture shows Phase A bi-direction active/reactive energy.</p> <p>EP+= 15452kWh,</p> <p>EP- = 2262kWh,</p> <p>EQ+ = 202kvarh,</p> <p>EQ- = 62kvarh.</p>

 <p>◀ 4 Quadrants Re. Energy ▶ 2.6</p> <p>#1 00000006300.000 kvarh</p> <p>#2 00000002000.000 kvarh</p> <p>#3 00000000500.000 kvarh</p> <p>#4 00000000700.000 kvarh</p>	<p>Left picture shows four-quadrant ractive energy.</p> <p>First quadrant Q1 = 6300kvarh,</p> <p>Second quadrant Q2 = 2000kvarh,</p> <p>Third quadrant Q3 = 500kvarh,</p> <p>Fourth quadrant Q4 = 700kvarh.</p>
 <p>◀ Spare Energy ▶ 2.8</p> <p>+ 00000015452.000 kWh</p> <p>- 00000003262.000 kWh</p> <p>+ 00000000202.000 kvarh</p> <p>- 00000000062.000 kvarh</p>	<p>Left picture show bi-directional spare active and reactive energy.</p> <p>EP+= 15452kWh,</p> <p>EP- = 3262kWh,</p> <p>EQ+ = 202kvarh,</p> <p>EQ- = 62kvarh.</p>
 <p>◀ Tariff Energy ▶ 2.9</p> <p>Σ 00000315452 .000 kWh</p> <p>T1 00000015452 .000 kWh</p> <p>T2 00000050000 .000 kWh</p> <p>T3 00000080000 .000 kWh</p> <p>T4 00000170000 .000 kWh</p>	<p>Left picture shows import active energy in different time zones.</p> <p>Total active energy (Σ) 315452kWh</p> <p>Energy of tariff 1 (T1) 15452kWh</p> <p>Energy of tariff 2 (T2) 50000kWh</p> <p>Energy of tariff 3 (T3) 80000kWh</p> <p>Energy of tariff 4 (T4) 170000kWh</p>

## 2.6 Energy quality

GPQM96 can monitor and analyze power quality of gird and measure the following variables:

Three phase voltage and current sequence component and unbalance

Electrical variables in three phase system can be divided into positive sequence component, negative sequence component and zero sequence component according to symmetrical component method. If electric system is in normal operation mode, the ratio between negative sequence component RMS value and positive sequence component RMS value is defined as three phase unbalance of an electrical variable.



◀ Volts Unbalance ▶ 3.1	
Posi-Seq Component	218.8 V
Neg-Seq Component	000.4 V
Zero-Seq Component	000.2 V
Unbalance Factor	0.001 %

Left picture shows three phase voltage and current sequence component and unbalance.

Phase voltage, line voltage and frequency deviation.

◀ L-N Voltage Deviation ▶ 3.3	
Δ V1	-10.00 kV
Δ V2	-10.00 kV
Δ V3	-10.00 kV

Left picture shows three phase voltage deviation.

Fundamental wave voltage/ current, harmonic voltage/current, fundamental wave active power/reactive power/apparent power, fundamental wave power factor.

◀ Fundamental Voltage ▶ 3.6	
V1	220.5 V
V2	220.6 V
V3	220.7 V

Left picture shows three phase voltage fundamental wave content.

Voltage short-term flicker, long-term flicker and fluctuation

◀ Short Term Severity ▶ 3.14	
L1	001.5
L2	001.6
L3	001.2

Left picture shows voltage short-term flicker value.

Voltage Fluctuation		
L1	010.5	V
L2	010.6	V
L3	010.7	V


Left picture shows voltage fluctuation value.

### Voltage and current phase angle

GPQM96 shows three phase voltage and current phase angles. L1 voltage angle is defaulted as 0°. Other phase angles are shown phase difference relative to L1 voltage. Unit: °

Phase Angle		
	U	I
L1	000.0 °	030.1 °
L2	120.0 °	150.0 °
L3	240.1 °	270.1 °

Left picture shows three phase voltage and current phase angles.



Left picture shows three phase voltage waveform.

### Voltage crest factor, current K factor

Crest Factor	
UKPR1	1.414
UKPR2	1.415
UKPR3	1.416

Left picture shows three phase voltage crest factor.

K Factor		3.20
IK1	1.155	
IK2	1.156	
IK3	1.157	

Left picture shows current K factor.

GPQM96 can measure harmonic content of grid. The detailed functions are as follows:


- Measuring 2<sup>nd</sup> to 63<sup>rd</sup> harmonics;
- Showing voltage and current bar graph.

THD			3.21
	THDV(%)	THDI(%)	
1	005.0	001.0	
2	003.0	002.0	
3	006.1	003.1	

Left picture shows three phase voltage and current THD.




Harmonic Ratio							3.22
	V1	V2	V3	I1	I2	I3	
01	100.0	100.0	100.0	100.0	100.0	100.0	
02	000.0	000.0	003.2	000.0	000.0	000.0	
03	005.0	000.0	000.0	000.0	000.0	000.0	
04	000.0	000.0	000.0	000.0	002.0	000.0	
05	000.0	000.0	000.0	007.0	000.0	000.0	
06	000.0	000.0	000.0	000.0	000.0	000.0	
07	000.0	000.0	000.0	000.0	000.0	003.7	
08	000.0	000.0	000.0	000.0	000.0	000.0	

Left picture shows three phase voltage and current subharmonics content.



## 2.7 Demand record

GPQM96 has six independent demand recording channels to measure and record max. demand, present demand and previous demand of three phase current, total active power, total reactive power and total apparent power.

	<p>Left picture shows present demand of three-phase current.</p>
	<p>Left picture shows three-phase total active power, reactive power, apparent power in last cycle.</p>
	<p>Left picture shows max. demand of three-phase total active power, reactive power and apparent power.</p>

## 2.8 Event record

Event record includes the total times and latest occurrence time of power on record, parameter modification record, over current record and so on.

<table border="1"> <thead> <tr> <th colspan="3">Event Log 1</th> <th style="text-align: right;">6.1</th> </tr> <tr> <th>Type</th> <th>Number</th> <th colspan="2">Last Record Time</th> </tr> </thead> <tbody> <tr> <td>Power On</td> <td>0036</td> <td colspan="2">17-01-13 08:25:16</td> </tr> <tr> <td>Power Off</td> <td>0036</td> <td colspan="2">17-01-12 17:01:20</td> </tr> <tr> <td>Setting</td> <td>0010</td> <td colspan="2">17-01-05 12:01:51</td> </tr> <tr> <td>Clr Demand</td> <td>0002</td> <td colspan="2">17-01-06 07:25:00</td> </tr> <tr> <td>Clr Energy</td> <td>0001</td> <td colspan="2">17-01-08 08:35:00</td> </tr> <tr> <td>Over Vlots</td> <td>0000</td> <td colspan="2"></td> </tr> <tr> <td>Loss Volts</td> <td>0000</td> <td colspan="2"></td> </tr> <tr> <td>Over Amps</td> <td>0000</td> <td colspan="2"></td> </tr> </tbody> </table>	Event Log 1			6.1	Type	Number	Last Record Time		Power On	0036	17-01-13 08:25:16		Power Off	0036	17-01-12 17:01:20		Setting	0010	17-01-05 12:01:51		Clr Demand	0002	17-01-06 07:25:00		Clr Energy	0001	17-01-08 08:35:00		Over Vlots	0000			Loss Volts	0000			Over Amps	0000			<p>Left picture shows event record 1.</p>
Event Log 1			6.1																																						
Type	Number	Last Record Time																																							
Power On	0036	17-01-13 08:25:16																																							
Power Off	0036	17-01-12 17:01:20																																							
Setting	0010	17-01-05 12:01:51																																							
Clr Demand	0002	17-01-06 07:25:00																																							
Clr Energy	0001	17-01-08 08:35:00																																							
Over Vlots	0000																																								
Loss Volts	0000																																								
Over Amps	0000																																								
<table border="1"> <thead> <tr> <th colspan="3">Event Log 2</th> <th style="text-align: right;">6.2</th> </tr> <tr> <th>Type</th> <th>Number</th> <th colspan="2">Last Record Time</th> </tr> </thead> <tbody> <tr> <td>Loss Amps</td> <td>0000</td> <td colspan="2"></td> </tr> <tr> <td>Over Load</td> <td>0000</td> <td colspan="2"></td> </tr> <tr> <td>Under load</td> <td>0000</td> <td colspan="2"></td> </tr> <tr> <td>Events</td> <td>0224</td> <td colspan="2"></td> </tr> <tr> <td>Volts Swell</td> <td>0016</td> <td colspan="2"></td> </tr> <tr> <td>Volts Sag</td> <td>0016</td> <td colspan="2"></td> </tr> <tr> <td>Loss Signal</td> <td>0016</td> <td colspan="2"></td> </tr> </tbody> </table>	Event Log 2			6.2	Type	Number	Last Record Time		Loss Amps	0000			Over Load	0000			Under load	0000			Events	0224			Volts Swell	0016			Volts Sag	0016			Loss Signal	0016			<p>Left picture shows event record 2.</p>				
Event Log 2			6.2																																						
Type	Number	Last Record Time																																							
Loss Amps	0000																																								
Over Load	0000																																								
Under load	0000																																								
Events	0224																																								
Volts Swell	0016																																								
Volts Sag	0016																																								
Loss Signal	0016																																								

## 2.9 Help information

The page shows software version and module status.

<table border="1"> <thead> <tr> <th colspan="2">About</th> </tr> </thead> <tbody> <tr> <td>Meter Type</td> <td>SFERE720</td> </tr> <tr> <td>Firmware Version</td> <td>1001.169A</td> </tr> <tr> <td>Meter Run Time</td> <td>0000648427 s</td> </tr> <tr> <td>Meter Load Time</td> <td>0000324557 s</td> </tr> <tr> <td>Tx1 Counter</td> <td>0000029220</td> </tr> <tr> <td>Rx1 Counter</td> <td>0000029230</td> </tr> <tr> <td>Tx2 Counter</td> <td>0000000000</td> </tr> <tr> <td>Rx2 Counter</td> <td>0000000000</td> </tr> <tr> <td>System Staus</td> <td>Voltage Err</td> </tr> </tbody> </table>	About		Meter Type	SFERE720	Firmware Version	1001.169A	Meter Run Time	0000648427 s	Meter Load Time	0000324557 s	Tx1 Counter	0000029220	Rx1 Counter	0000029230	Tx2 Counter	0000000000	Rx2 Counter	0000000000	System Staus	Voltage Err	<p>Left picture shows user help information. The last column shown present status of system. "OK" means the system operates normally. "Voltage Err" means there is voltage fault.</p>
About																					
Meter Type	SFERE720																				
Firmware Version	1001.169A																				
Meter Run Time	0000648427 s																				
Meter Load Time	0000324557 s																				
Tx1 Counter	0000029220																				
Rx1 Counter	0000029230																				
Tx2 Counter	0000000000																				
Rx2 Counter	0000000000																				
System Staus	Voltage Err																				

## 2.10 Extend module

GPQM96 has two extension interfaces for connecting modules and expand functions.

### 2.10.1 Digital input and relay output of GPQM96

GPQM96 has two digital inputs and two relay outputs.

◀ Local Digital I/O ▶ 5.1		
Digital Input		
No.	Mode	State
#1	PulseCount	0000000032
#2	On-Off	—/—
Relay Output		
No.	Mode	State
#1	Alarm	—/—
#2	Remote	—/—
◀ ▶ ↶ ↷		

Left picture shows digital input and relay output information of GPQM96.

### 2.10.2 Digital input (FM1, FM2)

FM1 module has digital input adopting wet contact mode to measure AC 220V signal.

FM2 module has digital input adopting dry contact mode which gets power supply from inside of meter and with no need for external power supply.

Digital input supports three working modes:

Status monitoring: the meter receives the status of terminal node and shows it on the window. It also shows the newest status immediately when the status of terminal node changes.

Pulse counting: the meter receives and counts up the number of pulses from terminals. It adds by one when it receives one pulse.

Spare energy: meter starts accumulating spare energy and stops accumulating total energy at the same time when it detects that the digital input becomes closed.

◀ Module X1 ▶ 5.2		
FM1(2DI/AC220V) Ver.166A		
No.	Mode	State
01	PulseCount	0000012345
02	On-Off	—/—
◀ ▶ ↶ ↷		

Left picture shows working modes of two digitals inputs are synchronous demand and status monitoring. No. 2 digital input receives signal.

◀ Module X2 ▶		5.3
FM2(4DI)		Ver.166A
No.	Mode	State
01	PulseCount	000000032
02	SpareEnergy	✓-
03	On-Off	✓-
04	On-Off	—
<div style="display: flex; justify-content: space-around; margin-top: 10px;"> <span>◀</span> <span>▶</span> <span>↶</span> </div>		

Left pictures shows workings modes of four digital inputs. No. 1 digital input is in pulse counting mode, and the pulse number is 32; No. 2 is spare energy, No. 3 and No. 4 digital inputs are in status monitoring mode, No.4 digital input has signal input.

### 2.10.3 Relay output (FM3)

GPQM96 has two relay outputs. FM3 module is used to add more relay outputs to meter. GPQM96 relay outputs have two working modes: remote control and off-limit alarm. FM3 module relay outputs have two working modes: remote control and off-limit alarm. Working mode, alarm item and alarm range of each relay output can be set in programming. As for detailed information about relay output setting, please refer to Appendix 2.

**Notice:**

Remote control

If user needs to remotely control relay output, please set the working mode as “Remote”. Set delay as electrical level mode or set delay time as N \* 100ms.

Off-limit alarm

Set relay output as “Alarm” mode, “Mode” is used to select an electrical variable, “Delay” is used to set alarm delay time, “Value” is used to set alarm limit value, “Reset” is used to set alarm recovery threshold value for electrical variable.

◀ Module X1 ▶		5.2
FM3(2DO)		Ver.166A
No.	Mode	State
01	Alarm	✓-
02	Remote	—
<div style="display: flex; justify-content: space-around; margin-top: 10px;"> <span>◀</span> <span>▶</span> <span>↶</span> </div>		

Left picture shows FM3 status information. No. 1 is in off-limit alarm mode, No. 2 is in remote control mode.

### 2.10.4 Analog input module (FM4)

FM4 module is used to measure 4~20mA signal. The measurement display page is shown as follows,

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2" style="text-align: left;">◀ Module X2 ▶ 5.3</th> </tr> <tr> <td colspan="2" style="text-align: center;">FM4(2A)/4-20mA Ver.166A</td> </tr> <tr> <th style="width: 15%;">No.</th> <th>Value</th> </tr> <tr> <td>01</td> <td>07.600 mA</td> </tr> <tr> <td>02</td> <td>18.200 mA</td> </tr> <tr> <td colspan="2" style="height: 40px;"></td> </tr> <tr> <td colspan="2" style="text-align: center;">◀ ▶ ⏪ ⏩</td> </tr> </table>	◀ Module X2 ▶ 5.3		FM4(2A)/4-20mA Ver.166A		No.	Value	01	07.600 mA	02	18.200 mA			◀ ▶ ⏪ ⏩		<p>Left picture shows DC analog input value. No. 1 input 7.6mA, No. 2 input 18.2mA.</p>
◀ Module X2 ▶ 5.3															
FM4(2A)/4-20mA Ver.166A															
No.	Value														
01	07.600 mA														
02	18.200 mA														
◀ ▶ ⏪ ⏩															

### 2.10.5 Analog input module (FM5)

FM5 module is used to measure PT100 signal. The measurement display page is shown as follows,

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2" style="text-align: left;">◀ Module X1 ▶ 5.2</th> </tr> <tr> <td colspan="2" style="text-align: center;">FM5(2Pt100) Ver.166A</td> </tr> <tr> <th style="width: 15%;">No.</th> <th>Value</th> </tr> <tr> <td>01</td> <td>075.5 °C</td> </tr> <tr> <td>02</td> <td>027.6 °C</td> </tr> <tr> <td colspan="2" style="height: 40px;"></td> </tr> <tr> <td colspan="2" style="text-align: center;">◀ ▶ ⏪ ⏩</td> </tr> </table>	◀ Module X1 ▶ 5.2		FM5(2Pt100) Ver.166A		No.	Value	01	075.5 °C	02	027.6 °C			◀ ▶ ⏪ ⏩		<p>Left picture shows PT100 input value. No.1 input temperature is 75.5°C, No.2 input temperature is 27.6°C.</p>
◀ Module X1 ▶ 5.2															
FM5(2Pt100) Ver.166A															
No.	Value														
01	075.5 °C														
02	027.6 °C														
◀ ▶ ⏪ ⏩															

### 2.10.6 Analog output module (FM6)


Analog output module can transfer instantenous electrical variables to DC current signal output. If analog output module is conneted to meter, the corresponding display page will be shown on meter. Current value shown in the page is theoretical output value in present status. Analog output item and range can be set through meter.

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2" style="text-align: left;">◀ Module X2 ▶ 5.3</th> </tr> <tr> <td colspan="2" style="text-align: center;">FM6(2AO)/4-20mA Ver.166A</td> </tr> <tr> <th style="width: 15%;">No.</th> <th>Value</th> </tr> <tr> <td>01</td> <td>12.500 mA</td> </tr> <tr> <td>02</td> <td>06.000 mA</td> </tr> <tr> <td colspan="2" style="height: 40px;"></td> </tr> <tr> <td colspan="2" style="text-align: center;">◀ ▶ ⏪ ⏩</td> </tr> </table>	◀ Module X2 ▶ 5.3		FM6(2AO)/4-20mA Ver.166A		No.	Value	01	12.500 mA	02	06.000 mA			◀ ▶ ⏪ ⏩		<p>Left picture shown analog output theoretical value. No. 1 output 12.5mA, No. 2 output 6mA.</p>
◀ Module X2 ▶ 5.3															
FM6(2AO)/4-20mA Ver.166A															
No.	Value														
01	12.500 mA														
02	06.000 mA														
◀ ▶ ⏪ ⏩															




## 3 Installation and wiring

### 3.1 Outline dimension




### 3.2 Installation method

- 1) Choose a right place on the fixed distribution cabinet for cutout by size 91×91mm;
- 2) Take off the supporting clips of the meter;
- 3) Insert the meter into the cutout;
- 4) Insert and push the supporting clips to fix the meter.



### 3.3 Wiring

Typical wiring for 3P4W, 4 CT, no PT




**Note:**

Auxiliary power supply: AC/DC (80~270)V

Rated current of fuse: 0.5A

### 3.4 Signal wiring diagram



Wiring instruction:

- External wiring method must be the same with the inner wiring method of the meter. Otherwise the measured data will be incorrect.
- Voltage and current signals must be AC signals. Please do not connection DC signals to input terminals.
- Voltage input: make sure the input voltage in not higher than the rated voltage of the meter, otherwise, please connect external PT to the meter. If external PT is adopted, the accuracy of meter will depend on the accuracy of external PT. Please make sure the accuracy of external PT


is equal to or better than that of meter. For your convenient maintenance, please adopt wiring terminal row.

(d) Current input: make sure the input current is not higher than the rated current of the meter, otherwise, please connect external CT to the meter. If external CT is adopted, the accuracy of meter will depend on the accuracy of external CT. Please make sure the accuracy of external CT is equal to or better than that of meter. If there is more than one meter connected to the CT, please connect them in serial. Before removing the current input wires of the meters, make sure to cut off the first loop of CT or short connect its second loop. For your convenient maintenance, please adopt wiring terminal row.

(e) Make sure voltage and current of three phases corresponding to each other, that means the phase sequence and direction are same. Otherwise, the numbers and signals will be incorrect (power and energy).

## 4. Operation

### 4.1 Panel description














A: Display window B. Function indication for keys C: Touch type keys

## 5 Setting

### 5.1 Signs for keys and corresponding functions




User can set parameters for meter through keys.


Sign	Function
	Add number at selected bit
	Move downward, switch to next page, change parameter
	Move left to change or show data/ switch data bit
	Move right to change or show data
	Return to Main interface directly, return to upper level menu/cancel modification
	Enter selected item
	Confirm
	Zoom display image
	Edit
	Next page
	Ineffective key

The method of changing numbers

Click  to select a bit, click  to add number at selected bit

Enter and exit programming status


**Enter programming mode:** Click  or  to select “System setting” in main interface, and then click  to enter programming interface. Select “User” and input correct password to enter parameter setting mode. (Programming password is defaulted as 0001 in factory. User can change the password.).

**Exit programming mode:** return to first level of menu at first, and then click . The meter will indicate whether to save modified data or not at this step. If “Yes” is selected, the meter will save modified data and return to main interface; if “No” is selected, the meter will cancel modified data and return to main interface.

## 5.2 Programming and setting menu

Programming and setting menu adopts hierarchical mode.

### 5.2.1 Basic parameter setting

	Backlight	00s-99 min 00-backlight constant on
	Bright	1-5
	Language	English
	Password	0001-9999
	Default display	Set first display interface after power on. This interface can be set as U, I, P, E, THD, Waveform, Demand and Max/Min
	Tariff Mode	Set tariff mode. This Can be set as Month Tariffs and Week(Holyday) Tariffs.
Impulse	0~999999	

### 5.2.2 Signal input setting

<table border="1"> <thead> <tr> <th colspan="2">Signal Inputs</th> </tr> </thead> <tbody> <tr> <td>Wiring</td> <td>3P4W</td> </tr> <tr> <td>PT Secondary</td> <td>0100 V</td> </tr> <tr> <td>PT Primary</td> <td>010000 V</td> </tr> <tr> <td>CT Secondary</td> <td>0001 A</td> </tr> <tr> <td>CT Primary</td> <td>000600 A</td> </tr> <tr> <td>In Secondary</td> <td>0001 A</td> </tr> <tr> <td>In Primary</td> <td>000600 A</td> </tr> </tbody> </table>	Signal Inputs		Wiring	3P4W	PT Secondary	0100 V	PT Primary	010000 V	CT Secondary	0001 A	CT Primary	000600 A	In Secondary	0001 A	In Primary	000600 A	Wiring method	1P2W,3P3W,3P4W
	Signal Inputs																	
	Wiring	3P4W																
	PT Secondary	0100 V																
	PT Primary	010000 V																
	CT Secondary	0001 A																
	CT Primary	000600 A																
	In Secondary	0001 A																
In Primary	000600 A																	
PT secondary value	0-690V																	
PT primary value	0-999999V																	
CT secondary value	0-6A																	
CT primary value	0-999999A																	
Neutral current primary value	0-999999A																	
Neutral current secondary value	0-6A																	

### 5.2.3 Communication setting

<table border="1"> <thead> <tr> <th colspan="2">Comm Settings</th> </tr> </thead> <tbody> <tr> <td>Address</td> <td>002</td> </tr> <tr> <td>Baudrate</td> <td>9600 bps</td> </tr> <tr> <td>Data Format</td> <td>N.8.1</td> </tr> <tr> <td>Protocol</td> <td>Modbus-RTU</td> </tr> </tbody> </table>	Comm Settings		Address	002	Baudrate	9600 bps	Data Format	N.8.1	Protocol	Modbus-RTU	Address	1~247
	Comm Settings											
	Address	002										
	Baudrate	9600 bps										
	Data Format	N.8.1										
Protocol	Modbus-RTU											
Baud rate	1200~38400bps											
Check mode	E81,O81,N81,N82											
Communication protocol	Modbus-RTU											

### 5.2.4 Digital input setting

<table border="1"> <thead> <tr> <th colspan="2">Digital Input Settings</th> </tr> </thead> <tbody> <tr> <td>No.</td> <td>Mode</td> </tr> <tr> <td>01</td> <td>PulseCount</td> </tr> <tr> <td>02</td> <td>On-Off</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>	Digital Input Settings		No.	Mode	01	PulseCount	02	On-Off									<p>There are three working modes of digital input.</p> <ul style="list-style-type: none"> <li>Pulse counting</li> <li>Status monitoring</li> <li>Spare energy</li> </ul>
Digital Input Settings																	
No.	Mode																
01	PulseCount																
02	On-Off																

### 5.2.5 Relay output setting

<table border="1"> <thead> <tr> <th colspan="2">Relay Output Settings</th> </tr> </thead> <tbody> <tr> <td>No.</td> <td>Mode</td> </tr> <tr> <td>01</td> <td>Alarm</td> </tr> <tr> <td>02</td> <td>Remote</td> </tr> </tbody> </table>	Relay Output Settings		No.	Mode	01	Alarm	02	Remote	<p>There are two working modes of relay output which are remote communication and alarm.</p>																
Relay Output Settings																									
No.	Mode																								
01	Alarm																								
02	Remote																								
<table border="1"> <thead> <tr> <th colspan="2">Relay Output Settings</th> </tr> </thead> <tbody> <tr> <td>Time</td> <td>00.00 s</td> </tr> <tr> <td>Item</td> <td>V1 &gt;</td> </tr> <tr> <td>Value</td> <td>240.0 V</td> </tr> <tr> <td>Hys</td> <td>030.0 V</td> </tr> <tr> <td>Delay</td> <td>000.0 s</td> </tr> </tbody> </table>	Relay Output Settings		Time	00.00 s	Item	V1 >	Value	240.0 V	Hys	030.0 V	Delay	000.0 s	<table border="1"> <thead> <tr> <th colspan="2">Alarm output Settings</th> </tr> </thead> <tbody> <tr> <td>Time</td> <td>Pulse width: 0.10~99.99s</td> </tr> <tr> <td>Item</td> <td>See following list</td> </tr> <tr> <td>Value</td> <td>Limit value</td> </tr> <tr> <td>Hys</td> <td>Hysteresis value</td> </tr> <tr> <td>Delay</td> <td>Delay time: (0~9999)×100ms</td> </tr> </tbody> </table>	Alarm output Settings		Time	Pulse width: 0.10~99.99s	Item	See following list	Value	Limit value	Hys	Hysteresis value	Delay	Delay time: (0~9999)×100ms
Relay Output Settings																									
Time	00.00 s																								
Item	V1 >																								
Value	240.0 V																								
Hys	030.0 V																								
Delay	000.0 s																								
Alarm output Settings																									
Time	Pulse width: 0.10~99.99s																								
Item	See following list																								
Value	Limit value																								
Hys	Hysteresis value																								
Delay	Delay time: (0~9999)×100ms																								
<table border="1"> <thead> <tr> <th colspan="2">Relay Output Settings</th> </tr> </thead> <tbody> <tr> <td>Time</td> <td>00.00 s</td> </tr> </tbody> </table>	Relay Output Settings		Time	00.00 s	<table border="1"> <thead> <tr> <th colspan="2">Remote control output mode</th> </tr> </thead> <tbody> <tr> <td>Time</td> <td>0-99.99s</td> </tr> </tbody> </table>	Remote control output mode		Time	0-99.99s																
Relay Output Settings																									
Time	00.00 s																								
Remote control output mode																									
Time	0-99.99s																								

Electrical variables for alarm are shown in the following list:

Item	Format	Instruction
OFF		Off
DI	0/1	Switching linkage action, relay acts according to digital input status. If it is 0, relay closes when digital input is 0; if it is 1, relay closes when digital input is 1.
X4.PT L	xxx.x °C	X4 low temperature alarm for any loop
X4.PT H		X4 high temperature alarm for any loop



X4.PT2L		X4 low temperature alarm for second loop
X4.PT2H		X4 high temperature alarm for second loop
X4.PT1L		X4 low temperature alarm for first loop
X4.PT1H		X4 high temperature alarm for first loop
X3.PT L		X3 low temperature alarm for any loop
X3.PT H		X3 high temperature alarm for any loop
X3.PT2L		X3 low temperature alarm for second loop
X3.PT2H		X3 high temperature alarm for second loop
X3.PT1L		X3 low temperature alarm for first loop
X3.PT1H		X3 high temperature alarm for first loop
X2.PT L		X2 low temperature alarm for any loop
X2.PT H		X2 high temperature alarm for any loop
X2.PT2L		X2 low temperature alarm for second loop
X2.PT2H		X2 high temperature alarm for second loop
X2.PT1L		X2 low temperature alarm for first loop
X2.PT1H		X2 high temperature alarm for first loop
X1.PT L		X1 low temperature alarm for any loop
X1.PT H		X1 high temperature alarm for any loop
X1.PT2L		X1 low temperature alarm for second loop
X1.PT2H		X1 high temperature alarm for second loop
X1.PT1L		X1 low temperature alarm for first loop
X1.PT1H		X1 high temperature alarm for first loop
dmd.S <	xxxx	Present demand S <
dmd.S >		Present demand S >
dmd.Q <		Present demand Q <
dmd.Q >		Present demand Q >
dmd.P <		Present demand P<
dmd.P >		Present demand P>
dmd.I <	x.xxx _A	Present demand I <

dmd.I >		Present demand I >
dmd.I3 <		Present demand I3<
dmd.I3 >		Present demand I3>
dmd.I2 <		Present demand I2<
dmd.I2 >		Present demand I2>
dmd.I1 <		Present demand I1<
dmd.I1 >		Present demand I1>
THDi <	xx.xx%	Current harmonic distortion rate low alarm
THDi >		Current harmonic distortion rate high alarm
THDv <		Voltage harmonic distortion rate low alarm
THDv >		Voltage harmonic distortion rate high alarm
Iunb <	xxx.x %	Current unbalance low alarm
Iunb >		Current unbalance high alarm
Vunb <		Voltage unbalance low alarm
Vunb >		Voltage unbalance high alarm
F <	xx.xx Hz	Grid frequency low alarm
F >		Grid frequency high alarm
PF <	x.xxx	Total power factor low alarm
PF >		Total power factor high alarm
S <	xxxx _VA	Total apparent power low alarm
S >		Total apparent power high alarm
Q <	xxxx _var	Total reactive power low alarm
Q >		Total reactive power high alarm
P <	xxxx _W	Total active power low alarm
P >		Total active power high alarm
Io <	x.xxx _A	Zero-sequence current low alarm
Io >		Zero-sequence current high alarm
Iavg >		Current average value low alarm
Iavg <		Current average value high alarm

I <		One of three phase currents low alarm
I >		One of three phase currents high alarm
I3 <		I3 low alarm
I3 >		I3 high alarm
I2 <		I2 low alarm
I2 >		I2 high alarm
I1 <		I1 low alarm
I1 >		I1 high alarm
Vllavg <		Line voltage average value low alarm
Vllavg >		Line voltage average value high alarm
Vlnavg <		Phase voltage average value low alarm
Vlnavg >		Phase voltage average value high alarm
VII <		One of three line-voltages low alarm
VII >		One of three line-voltages high alarm
V31 <		V31 voltages low alarm
V31 >		V31 voltages high alarm
V23 <		V23 voltages low alarm
V23 >		V23 voltages high alarm
V12 <	xxx.x _V	V12 voltages low alarm
V12 >		V12 voltages high alarm
Vln <		One of three phases voltages low alarm
Vln >		One of three phases voltages high alarm
V3 <		V3 voltages low alarm
V3 >		V3 voltages high alarm
V2 <		V2 voltages low alarm
V2 >		V2 voltages high alarm
V1 <		V1 voltages low alarm
V1 >		V1 voltages high alarm


### 5.2.6 Limit value setting

<table border="1"> <thead> <tr> <th colspan="3">Limits #1</th> </tr> <tr> <th>Item</th> <th>Value</th> <th>Hys</th> </tr> </thead> <tbody> <tr> <td>Over Volts</td> <td>245.6 V</td> <td>010.0 V</td> </tr> <tr> <td>Under Volts</td> <td>190.0 V</td> <td>010.0 V</td> </tr> <tr> <td>Over Amps</td> <td>006.0 A</td> <td>0.200 A</td> </tr> <tr> <td>Under Amps</td> <td>0.000 A</td> <td>0.000 A</td> </tr> <tr> <td>Over Power</td> <td>3600 W</td> <td>0100 W</td> </tr> <tr> <td>Under Power</td> <td>0000 W</td> <td>0000 W</td> </tr> </tbody> </table>	Limits #1			Item	Value	Hys	Over Volts	245.6 V	010.0 V	Under Volts	190.0 V	010.0 V	Over Amps	006.0 A	0.200 A	Under Amps	0.000 A	0.000 A	Over Power	3600 W	0100 W	Under Power	0000 W	0000 W	<p>Used for setting off-limit alarm for voltage, current and power.</p>
Limits #1																									
Item	Value	Hys																							
Over Volts	245.6 V	010.0 V																							
Under Volts	190.0 V	010.0 V																							
Over Amps	006.0 A	0.200 A																							
Under Amps	0.000 A	0.000 A																							
Over Power	3600 W	0100 W																							
Under Power	0000 W	0000 W																							
<table border="1"> <thead> <tr> <th colspan="3">Limits #2</th> </tr> <tr> <th>Item</th> <th>Value</th> <th>Hys</th> </tr> </thead> <tbody> <tr> <td>Swell</td> <td>400.0 V</td> <td>001.0 V</td> </tr> <tr> <td>Dip</td> <td>190.0 V</td> <td>001.0 V</td> </tr> <tr> <td>Interruptions</td> <td>030.0 V</td> <td>001.0 V</td> </tr> <tr> <td>Swell/Dips</td> <td colspan="2">Disable</td> </tr> </tbody> </table>	Limits #2			Item	Value	Hys	Swell	400.0 V	001.0 V	Dip	190.0 V	001.0 V	Interruptions	030.0 V	001.0 V	Swell/Dips	Disable		<p>Used for setting voltage swell, sag and interruption.</p>						
Limits #2																									
Item	Value	Hys																							
Swell	400.0 V	001.0 V																							
Dip	190.0 V	001.0 V																							
Interruptions	030.0 V	001.0 V																							
Swell/Dips	Disable																								
<table border="1"> <thead> <tr> <th colspan="3">Limits #3</th> </tr> <tr> <th>Item</th> <th>Value</th> <th>Hys</th> </tr> </thead> <tbody> <tr> <td>Rec Over Volt</td> <td>520.0 V</td> <td>005.1 V</td> </tr> <tr> <td>Rec Under Volt</td> <td>080.0 V</td> <td>005.0 V</td> </tr> <tr> <td>Rec Over Amp</td> <td>5.500 A</td> <td>0.100 A</td> </tr> <tr> <td>Disturb Record</td> <td colspan="2">Enable</td> </tr> </tbody> </table>	Limits #3			Item	Value	Hys	Rec Over Volt	520.0 V	005.1 V	Rec Under Volt	080.0 V	005.0 V	Rec Over Amp	5.500 A	0.100 A	Disturb Record	Enable		<p>Used for setting over voltage, under voltage and over current in fault wave record.</p>						
Limits #3																									
Item	Value	Hys																							
Rec Over Volt	520.0 V	005.1 V																							
Rec Under Volt	080.0 V	005.0 V																							
Rec Over Amp	5.500 A	0.100 A																							
Disturb Record	Enable																								


### 5.2.7 Clear synchronous setting

<table border="1"> <thead> <tr> <th colspan="2">Reset Data</th> </tr> </thead> <tbody> <tr> <td>Reset Energy</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Reset Demand</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Reset Limit</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Res.SystemEvent</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Reset SOE</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Reset Alarm</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Res.LoadRecord</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Res.PulseCounter</td> <td><input type="checkbox"/></td> </tr> </tbody> </table>	Reset Data		Reset Energy	<input type="checkbox"/>	Reset Demand	<input type="checkbox"/>	Reset Limit	<input type="checkbox"/>	Res.SystemEvent	<input type="checkbox"/>	Reset SOE	<input type="checkbox"/>	Reset Alarm	<input type="checkbox"/>	Res.LoadRecord	<input type="checkbox"/>	Res.PulseCounter	<input type="checkbox"/>	<p>Parameters of energy, demand, Max./Min. value and Event are cleared in this interface. If the parameters are cleared, the relative value will be zero and not be reset; If energy is cleared, a piece of energy clearance SOE is made.</p>
Reset Data																			
Reset Energy	<input type="checkbox"/>																		
Reset Demand	<input type="checkbox"/>																		
Reset Limit	<input type="checkbox"/>																		
Res.SystemEvent	<input type="checkbox"/>																		
Reset SOE	<input type="checkbox"/>																		
Reset Alarm	<input type="checkbox"/>																		
Res.LoadRecord	<input type="checkbox"/>																		
Res.PulseCounter	<input type="checkbox"/>																		

### 5.2.8 Time setting and meter reading time

	System time	Setup real-time-clock
	Meter reading time	
	DST	Daylight Saving Time Mode
	DST Zone	Daylight Saving Time Zone


### 5.2.9 Demand setting

	No.	1-6
	Item	I1,I2,I3,P,Q,S
	Mode	Slip/Fixed
	t	Update time
	T	$T=n*t,$


There are two demand measurement modes which are slip and fixed. The relative time parameters are set as t (updating time) and T (time zone).

**Slip:** meter calculates average demand during latest T minutes every t seconds, tests and records the value, automatically reads the demand every month;

**Fixed:** meter calculates average demand during latest T minutes after T minutes, tests and records the value, automatically reads the demand every month.



Fixed mode



Slip mode

Note: calculation method in upper pictures takes 15min as example.

### 5.2.10 Monthly tariff setting

Month Tariffs			
Month	Day Type	Month	Day Type
01	#2	07	#1
02	#1	08	#1
03	#1	09	#1
04	#1	10	#1
05	#2	11	#1
06	#1	12	#1

GPQM96 has two sets of daily tariffs. One month can be selected to follow one set of daily tariffs. Daily tariffs can be set in daily tariff page.


### 5.2.11 Daily tariff setting

◀ #1 Day Tariffs ▶					
No.	Time	Tariffs	No.	Time	Tariffs
01	00:00	T2	07	00:00	T1
02	08:00	T1	08	00:00	T1
03	20:00	T3	09	00:00	T1
04	22:00	T4	10	00:00	T1
05	00:00	T1	11	00:00	T1
06	00:00	T1	12	00:00	T1

GPQM96 has two sets of daily tariffs. 24 hours in a day are divided into 12 twelve zone. Each time zone can be selected with one from fours kinds of tariffs.

## 5.3 Example for programming operation

Suppose the wiring method of meter is three phase four wire and primary voltage is 10KV, change the wiring method to be three phase three wire and change primary voltage to be 6000V, the programming operation process is as follows,



## 6. Communication

Meter is defaulted to be equipped with one communication, RS-485 interface, Modbus-RTU protocol. It also can be extended with one communication by connecting with a module.



## 7. Technical specifications

Electric Characteristics			
Accuracy	Voltage and current		0.2%
	Power, Power Factor		0.2%
	Frequency		±0.01Hz
	Active power		IEC62053-22, class 0.2S
	Reactive power		IEC62053-23, class 2
Data update rate		1s	
Input	Wiring mode		1P2W、3P3W、3P4W
	Voltage	Rated value	400 VAC L-N (690 VAC L-L)
		Overload	1.2VIn
		Impedance	>1MΩ
	Current	Rated value	1A or 5A
		Overload	Continuous: 1.2In
			Instantaneous: 10In/5s
		burden	<0.1VA
Rated value	<20mΩ		
Grid frequency		(45~65)Hz	
Auxiliary supply	Working range	AC/DC (80~270) V	
	consumption	≤ 10VA	
Energy pulse output		1 photocoupler outputs, pulse width (80±20%) ms	
Digital input		AC220V input, isolation: 2000VAC	
Relay output		Contact rated at AC 250V/5A or DC 30V/5A	
		Isolation: 2500VAC	
Communications			
RS485 port		Modbus-RTU, 2-wire, up to 38400bps	
Mechanical Characteristics			
IP index	IP65 (front panel) and IP20 (meter body)		
Dimensions	96×96×55mm		

Environmental Characteristics	
Operating temperature	(-10~60)°C
Storage temperature	(-25~70)°C
Relative humidity	(5~95)% (no gel)
Insulation	IEC 61010-1
Electromagnetic Compatibility	
Immunity to electrostatic discharge	IEC 61000-4-2-Level III
Immunity to radio-frequency field	IEC 61000-4-3- Level III
Immunity to electrical fast transients/bursts	IEC 61000-4-4- Level IV
Immunity to impulse waves	IEC 61000-4-5- Level IV
Immunity to conducted disturbances	IEC 61000-4-6- Level III
Immunity to power frequency magnetic fields	IEC 61000-4-8- Level III
Immunity to voltage dips and short interruptions	IEC 61000-4-11- Level III

Eetarp Engineering Pte Ltd | CRN: 200001617K

Electrical Safety | Power Quality | Energy Management

11 Woodlands Close, #08-13 | Woodlands 11

Singapore 737853

Tel: +65 6339 3651 | Fax: +65 6339 3667

Email: info@eetarp.com | Web: www.eetarp.com

Eetarp Power (M) Sdn Bhd | CRN: 201601034287

Electrical Safety | Power Quality | Energy Management

A-5-11 Blk Allamanda | 10 Boulevard, Lebuhraya Sprint

PJU 6A, 47400, PJ | Selangor, Malaysia

Tel: +60 3 7729 3973 | Fax: +603 7729 8973

Email: info@eetarp.com | Web: www.eetarp.com

Document No.: EEPL-UM-GPQM96-Rev00

---

The information in this document is subject to change without further notice.